

Water Test vitavit®:

1. Fill in water above the min level (not more than 1 cup).
2. Close the pressure cooker, set the cooking valve on setting 1 or 2 and put it on the stove.
3. Turn heat to maximum (very important)
4. Steam should come out from under the lid handle.
5. After a few minutes the steam should stop to come out from under the handle.
6. If the steam still comes out from under the handle after 12 minutes and the pressure cooker is still on maximum heat and the water is boiling inside the pot, something is wrong and please let me know.
7. If the valve closes, the indicator should start rising and you have to turn down the heat so that you can see the yellow or green ring but not the red one. If you see only the yellow and green ring, the pressure cooker should be completely silent and no water should drip from any valves.
8. If you see the red ring, your pressure cooker has too much pressure and the excessive pressure will be released. That will create a hissing sound and even some water may drop out of the valves. You can bring it back to normal by reducing the heat or turn off the heat completely for a while until the hissing sound stops and you do not see the red ring anymore.

